



Proper blade angle is necessary to provide optimal grip strength. Be sure to adjust blade as needed for your specific smartphone/case, using a #1 Philips screwdriver. Do not overtighten the screws, as this may damage the blade shoulders, the thumbstud, or even the blade itself.

Blade open but without phone  
[note blade angle]



Proper blade angle  
with phone loaded  
[firm grip strength]



Improper blade angle  
with phone loaded  
[weak grip strength]

